



ISO Registered Company

MODEL 345

PRESSURE REDUCING REGULATOR

SECTION I


I. DESCRIPTION AND SCOPE

The Model 345 is a diaphragm-less, heavy duty, high pressure reducing regulator used to control downstream (outlet or P_2) pressure. Sizes are 1/2", 3/4", 1" (DN15, 20, and 25). With proper trim utilization, the unit is suitable for liquid and gaseous service. Refer to Technical Bulletin 345-TB for design conditions and selection recommendations. **NOT FOR STEAM SERVICE.**

SECTION II

II. INSTALLATION

1. An inlet block valve should always be installed.
2. If service application is continuous such that shutdown is not readily accomplished, it is recommended that an inlet block valve, outlet block valve, and a manual bypass valve be installed.
3. Pipe unions should be installed to allow removal from piping.
4. An outlet pressure gauge should be located approximately ten pipe diameters downstream, and within sight.
5. All installations should include a downstream relief device if the inlet pressure could exceed the pressure rating of any downstream equipment or the maximum outlet pressure rating of the unit.



8. Flow Direction: Install so the flow direction matches the arrow cast on the main regulator body.
9. Basic Regulator - (Refer to Figure 1): Regulator may be rotated around the pipe axis 360°. Recommended position is with spring chamber vertical upwards. Orient such that the spring chamber vent hole does not collect rainwater or debris.
10. Regulators are not to be direct buried underground.

⚠ CAUTION

DONOT HYDROSTATIC TEST THROUGH AN INSTALLED UNIT; ISOLATE REGULATOR FROM TEST. Internal mechanical damage could result. Refer to Technical Bulletin Model 345, Table 5 for "emergency overpressure level" that will not do irreparable damage. In addition, note on nameplate that Inlet and Outlet pressure ratings are at different levels.

6. Clean the piping of all foreign material including chips, welding scale, oil, grease and dirt before installing the regulator. Strainers are recommended.
7. In placing thread sealant on pipe ends prior to engagement, assure that excess material is removed and not allowed to enter the regulator upon startup.

⚠ CAUTION

Installation of adequate overpressure protection is recommended to protect the regulator from overpressure and all downstream equipment from damage in the event of regulator failure.

⚠ CAUTION

For welded installations, all internal trim parts, seals and diaphragm(s) must be removed from regulator body prior to welding into pipeline. The heat of fusion welding will damage non-metallic parts if not removed. NOTE: This does not apply to units equipped with extended pipe nipples.

SECTION III

III. PRINCIPLE OF OPERATION

Movement occurs as pressure variations register on the pressure piston. The registering pressure is the outlet, P_2 , or downstream pressure. The range spring opposes pressure piston movement. As outlet pressure drops, the range spring pushes the pressure piston down, opening the port; as outlet pressure increases, the pressure piston pushes up and the port opening closes.

SECTION IV

IV. STARTUP

1. Start with the block valves closed. A bypass valve may be used to maintain outlet pressure in the downstream system without changing the following steps.
2. Relax the range spring by turning the T-bar handle adjusting screw counter clockwise (CCW) a minimum of three (3) full revolutions. This reduces the outlet (downstream) pressure set point.
3. If it is a "hot" piping system, and equipped with a bypass valve, slowly open the bypass valve to pre-heat the system piping and to allow slow expansion of the piping. Closely monitor outlet (downstream) pressure via gauge to assure not over-pressurizing. NOTE: If no bypass valve is installed, extra caution should be used in starting up a cold system; i.e. do everything slowly.
4. Crack open the outlet (downstream) block valve.
5. Slowly open the inlet (upstream) block valve observing the outlet (downstream) pressure gauge. Determine if the regulator is flowing. If not, slowly rotate the regulator T-bar adjusting screw handle clockwise (CW) until flow begins.
6. Continue to slowly open the inlet (upstream) block valve until fully open.
7. Continue to slowly open the outlet (downstream) block valve, especially when the downstream piping system isn't pressurized. If the outlet (downstream) pressure exceeds the desired pressure, close the block valve and go to Step 2, then return to Step 4.
8. When flow is established steady enough that the outlet (downstream) block valve is fully open, begin to slowly close the bypass valve if installed.
9. Develop system flow to a level near its expected normal rate, and reset the regulator set point by turning the T-bar adjusting screw handle CW to increase outlet pressure, or CCW to reduce outlet pressure.
10. Reduce system flow to a minimum level and observe set point. Outlet pressure will rise from the set point of Step 9. The maximum rise in outlet pressure on decreasing flow should not exceed the stated upper limit of the range spring by greater than 10%; i.e. 500 to 1000 psig (34.5 to 68.9 Barg) range spring, at low flow the outlet pressure should not exceed 1100 psig (75.8 Barg), if it does, consult factory.

SECTION V

V. SHUTDOWN

1. On systems with a bypass valve, and where system pressure is to be maintained as the regulator is shut down, slowly open the bypass valve while closing the inlet (upstream) block valve. Fully close the inlet (upstream) block valve. (When on bypass, the system pressure must be constantly observed and manually regulated.) Close the outlet (downstream) block valve.

CAUTION

Do not walk away and leave a bypassed regulator unattended!

2. If the regulator and system are to both be shutdown, slowly close the inlet (upstream) block valve. Close the outlet (downstream) valve only if regulator removal is required.

SECTION VI

VI. MAINTENANCE:



WARNING

SYSTEM UNDER PRESSURE. Prior to performing any maintenance, isolate the regulator from the system and relieve all pressure. Failure to do so could result in personal injury.

A. General:

1. Maintenance procedures hereinafter are based upon removal of the regulator unit from the pipeline where installed.
2. Owner should refer to owner's procedures for removal, handling, cleaning and disposal of non-reusable parts, i.e. gaskets, etc.
3. Refer to Figure 1 for the basic regulator, metal seat design and Figure 2 for a blow-up of the balanced TFE trim.

B. Pressure Piston/O-Ring: Inspection/ Replacement:

1. Securely install the body (1) in a vise with the spring chamber (2) directed upwards.



WARNING

SPRING UNDER COMPRESSION. Prior to removing spring chamber, relieve spring compression by backing out the T-bar adjusting screw. Failure to do so may result in flying parts that could cause personal injury.

2. Relax range spring (14) by turning T-bar adjusting screw handle (6) CCW to release spring compression.
3. Grasp hexagon portion (w/proper wrench) of the spring chamber (2) and turn CCW to remove.
4. Remove the thrust bearing (9), range spring (14), and spring button (4).
5. Pull the pressure piston (3) directly out of the body. Inspect the body quad ring (11) and body back up ring (12). If nicked or scratched, replace. Apply a light coating of lubricant to body quad ring (11) when replacing.
6. Inspect pressure piston (3) to assure no deformation due to over-pressurization. If deformed, replace.
7. Reverse steps 1 through 5 for reassembly. Make

sure spring chamber (2) is tightened fully down against body (1).

C. Trim Replacement (For Metal Seated Units):

1. Install body (1) in a vise with the body cap (5) on top.
2. Using a 5/16" Allen wrench, remove socket head cap screws (21). Carefully remove body cap from body.
3. Remove piston spring (17), piston (15 or 15.1), cylinder (16 or 15.2) and cylinder gasket (18). Inspect parts for excessive wear, especially at seat surfaces. Replace if worn, nicked, or depressed.
4. Remove body cap o-ring (13) and clean contacting surface of body. Clean flat mating surfaces of body (1) to body cap (5) shoulder.
5. Clean debris from within regulator body (1) cavity. Clean parts to be reused. **NOTE:** *On regulators originally supplied as "oxygen clean", option 345-55, maintenance must include a level of cleanliness equal to Cashco's cleaning standard #S-1134. Contact factory for details.*
6. Replace cylinder gasket (18) on cylinder (16 or 15.2)
7. Reinstall the cylinder (16 or 15.2) and cylinder gasket (18) into body cavity.
8. Slide the piston (15.1) slowly into place, assuring that the piston (15.1) post slides into the pressure piston (3).
9. Carefully place piston spring (17) directly on top of the piston (15.1).
10. Install body cap o-ring (13) on body cap (5) and carefully place body cap (5) into body (1). Replace socket head cap screws (21) and tighten with a 5/16" Allen wrench. Recommended torque is as follows:

Regulator Size	Cap Screw Size	Torque
1/2", 3/4" & 1" (DN15, 20, 25)	3/8"-16-1" skt.hd cap screw	50 ft./lbs. (68 N-m)

NOTE: *Never replace the socket head cap screws (21) with just any bolting. Use only the proper size and grade as replacement.*

11. Bench test unit for suitable operation. **NOTE:** *Regulators are not tight shutoff devices. Even if pressure builds up beyond set point, a regulator may or may not develop bubble tight shutoff. In general, tighter shutoff can be expected with composition seat.*

12. Soap test around body cap (5) and body(1) for leakage. Test pressure should be a minimum of 100 psig (6.9 Barg) at the inlet and leakage determined by bubbles.

D. Trim Replacement (For TFE Seated Units):

1. Follow same steps as listed under trim replacement for metal seated units, except for the following guidelines:
 - a. After removing the body cap(5) (C.2), inspect the inside surface of the body cap for scratches or nicks. These could result in leakage past the quad ring (19) and backup ring (20). If worn or scratched replace the body cap (5).
 - b. When inspecting parts for excessive wear (C.3), assure there are no foreign particles embedded in the teflon seat. Inspect for nicks. Inspect the backup ring (20) and quad ring (19) on piston post.

c. Remove the body cap o-ring (13) and clean contacting surface of body.

2. To check for seat leakage, follow same steps as listed under Pressure Piston/O-ring Inspection/Replacement, except for the following guidelines:

- a. Pour a small amount of water in on top of the piston (through pressure piston bore in body). Crack open inlet pressure (50 psig maximum) to body and visually check for leakage by the cylinder gasket (18), TFE seat (15), or the body quad ring (19). After inspection, assure that water is removed before completing assembly and installing in line.

NOTE: *When piston (15) assemblies are used with comp seats, Cashco, Inc. does not recommend attempting to remove the comp seat. If composition seat is damaged, replace entire piston assembly.*

SECTION VII

VII. TROUBLE SHOOTING GUIDE

1. Erratic operation.

Possible Causes	Remedies
A. Oversized regulator; inadequate rangeability.	A1. Check actual flow conditions, re-size regulator for minimum and maximum flow. A2. Increase flow rate. A3. Decrease regulator pressure drop; decrease inlet pressure by placing a throttling orifice in inlet piping union. A4. Install next step higher range spring. A5. Before replacing regulator contact factory
B. Worn piston/cylinder; inadequate guiding.	B. Replace trim.
C. Weakened/broken piston spring.	C. Replace piston spring.

2. Sluggish operation.

Possible Causes	Remedies
A. Plugged piston balance port.	A. Remove trim and clean balance port.
B. Fluid too viscous.	B. Heat fluid. Contact factory.

3. Downstream Pressure will not reach desired setting

Possible Causes	Remedies
A. Regulator undersized.	A1. Confirm by opening bypass valve together with regulator. A2. Check actual flow conditions, re-size regulator; if regulator has inadequate capacity, replace with larger unit.
B. Plugged trim.	B. Remove trim and check for plugged holes in cylinder.
C. Incorrect range spring (screwing in CW of adjusting screw does not allow bringing pressure level up to proper level).	C. Replace range spring with proper higher range. Contact factory.
D. Too much droop.	D1. Review droop expected. D2. Contact factory.
E. Restricted pressure piston movement.	E. Assure no moisture in spring chamber at temperatures below freeze point. Assure no dust or debris entering vent openings.

4. Leakage through the spring chamber vents.

Possible Causes	Remedies
A. Failure of body quad ring and body backup ring.	A. Inspect the pressure piston, body quad ring and body backup ring. If scratched, nicked, or deformed - replace.

5. Excessive pressure downstream.

Possible Causes	Remedies
A. Regulator not closing tightly.	A.1. Inspect the seating. Clean and lap metal seat surfaces; replace if lapping does not remedy. If composition seats are depressed, nicked or embedded with debris, replace trim. A2. Inspect guides in body cap (Balanced trim). If damaged, replace body cap and/or piston, quad ring and back up ring.
B. Downstream block.	B. Check system; isolate (block) flow at regulator inlet - not outlet. Relocate regulator if necessary.
C. No pressure relief protection.	C. Install safety relief valve, or rupture disc.
D. Restricted pressure piston movement.	D. Assure no moisture in spring chamber at temperatures below freeze point. Assure no dust or debris entering vent openings.

6. Excessive seat leakage.

Possible Causes	Remedies
A. Foreign matter on seating surface, erosion of seating surface, scratched body cap.	A. Inspect and replace damaged parts.
B. Balanced trim	B. Inspect piston quad ring and back up ring. Replace if damaged.

SECTION VIII

VIII. ORDERING INFORMATION

NEW REPLACEMENT UNIT vs PARTS "KIT" FOR FIELD REPAIR

To obtain a quotation or place an order, please retrieve the Serial Number and Product Code that was stamped on the metal name plate and attached to the unit. This information can also be found on the Bill of Material ("BOM"), a parts list that was provided when unit was originally shipped. (Serial Number typically 6 digits). Product Code typical format as follows: (last digit is alpha character that reflects revision level for the product).

□□□□-□□□□7-□□□□□□□□□□

NEW REPLACEMENT UNIT:

Contact your local Cashco, Inc., Sales Representative with the Serial Number and Product code. With this information they can provide a quotation for a new unit including a complete description, price and availability.



CAUTION

Do not attempt to alter the original construction of any unit without assistance and approval from the factory. All purposed changes will require a new name plate with appropriate ratings and new product code to accommodate the recommended part(s) changes.

PARTS "KIT" for FIELD REPAIR:

Contact your local Cashco, Inc., Sales Representative with the Serial Number and Product code. Identify the parts and the quantity required to repair the unit from the "BOM" sheet that was provided when unit was originally shipped.

NOTE: *Those part numbers that have a quantity indicated under "Spare Parts" in column "A" reflect minimum parts required for inspection and rebuild, - "Soft Goods Kit". Those in column "B" include minimum trim replacement parts needed plus those "Soft Goods" parts from column "A".*

If the "BOM" is not available, refer to the cross-sectional drawings included in this manual for part identification and selection.

A Local Sales Representative will provide quotation for appropriate Kit Number, Price and Availability.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such product at any time without notice. Cashco, Inc. does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Cashco, Inc. product remains solely with the purchaser.




Figure 1: Basic Model 345 with metal seat design.




Figure 2: Composition Seat Design

Item No.	Description	Item No.	Description
1	Body	13	Body Cap O-Ring ‡
2	Spring Chamber	14	Range Spring
3	Pressure Piston	15	Piston - Comp
4	Spring Button	15.1	Piston-Metal ‡
5	Body Cap	15.2	Cylinder-Metal ‡
6	Adjusting Screw	16	Cylinder-Comp
7	Set Screw	17	Piston Spring ‡
8	T-Bar Handle	18	Cylinder Gasket ‡
9	Thrust Bearing	19	Piston Quad Ring
10	Name Plate	20	Piston Backup Ring
11	Body Quad Ring ‡	21	Socket Head Cap Screw (6)
12	Body Backup Ring ‡		

‡ Available with Parts Kit B

ATEX 2014/34/EU: Explosive Atmospheres and Cashco Inc. Products



Cashco, Inc. declares that the products listed in the table below has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II of the ATEX Directive 2014/34/EU. Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN ISO 80079-36:2016 and EN ISO 80079-37:2016. The product will be marked as follows:

CE Ex II 2 G
Ex h IIB T6... T1 Gb
1000ATEXR1 X

The 'X' placed after the technical file number indicates that the product is subject to specific conditions of use as follows:

1. The maximum surface temperature depends entirely on the operating conditions and not the equipment itself. The combination of the maximum ambient and the maximum process medium temperature shall be used to determine the maximum surface temperature and corresponding temperature classification, considering the safety margins described prescribed in EN ISO 80079-36:2016, Clause 8.2. Additionally, the system designer and users must take precautions to prevent rapid system pressurization which may raise the surface temperature of system components and tubing due to adiabatic compression of the system gas. Furthermore, the Joule-Thomson effect may cause process gases to rise in temperature as they expand going through a regulator. This could raise the external surface temperature of the regulator body and the downstream piping creating a potential source of ignition. Whether the Joule-Thomson effect leads to heating or cooling of the process gas depends on the process gas and the inlet and outlet pressures. The system designer is responsible for determining whether the process gas temperature may raise under any operating conditions.
2. Where the process medium is a liquid or semi-solid material with a surface resistance in excess of 1GΩ, special precautions shall be taken to ensure the process does not generate electrostatic discharge.
3. Special consideration shall be made regarding the filtration of the process medium if there is a potential for the process medium to contain solid particles. Where particles are present, the process flow shall be <1m/s (<3.3 ft/s) in order to prevent friction between the process medium and internal surfaces.
4. Effective earthing (grounding) of the product shall be ensured during installation.
5. The valve body/housing shall be regularly cleaned to prevent build up of dust deposits.
6. Regulators must be ordered with the non-relieving option (instead of the self-relieving option) if the process gas they are to be used with is hazardous (flammable, toxic, etc.). The self-relieving option vents process gas through the regulator cap directly into the atmosphere while the non-relieving option does not. Using regulators with the self-relieving option in a flammable gas system could create an explosive atmosphere in the vicinity of the regulator.
7. Tied diaphragm regulators with outlet ranges greater than 7 barg (100 psig) should be preset to minimize the risk that improper operation might lead to an outboard leak and a potentially explosive atmosphere.
8. All equipment must only be fitted with manufacturer's original spare parts.
9. Ensure that only non-sparking tools are used, as per EN 1127-1, Annex A.

	PRODUCT
	31-B, 31-N
	1164, 1164(OPT-45)
	1171, 1171(OPT-45), 1171(CRYO)
	2171, 2171(OPT-45), 2171(CRYO), 3171
	1465, 3381, 3381(OPT-45), 3381(OPT-40)
	4381, 4381(OPT-37), 4381(CRYO), 4381(OPT-45), 5381
	MPRV-H, MPRV-L
	PBE, PBE-L, PBE-H
	CA-1, CA-2
	CA1, SA1, CA4, SA4, CA5, SA5
	DA2, DA4, DA5, DA6, DA8
	DA0, DA1, DAP, SAP
	SLR-1, SLR-2, PTR-1
	ALR-1, ULR-1, PGR-1
	BQ, BQ(OPT-45), BQ(CRYO)
	123, 123(CRYO), 123(OPT-45), 123(OPT-46G)
	123-1+6, 123-1+6(OPT-45), 123-1+6(OPT-46G), 123-1+6+S, 123-1+6+S(OPT-40)
	1000HP, 1000HP(OPT-37), 1000HP(OPT-45), 1000HP(OPT-45G), 1000HP(CRYO)
	1000HP-1+6, 1000HP-1+8, 1000LP, 1000LP(OPT-45), 1000LP(OPT-46G)
	6987
	8310HP, 8310HP-1+6, 8310HP-1+8, 8310LP, 8311HP, 8311LP
	345, 345(OPT-45)
	BA1/BL1, PA1/PL1
	C-BPV, C-PRV, C-CS
	D, D(CRYO), D(OPT-37), D(OPT-20), D(OPT-45)
	DL, DL(LCC), DL(OPT-45)
	BR, BR(CRYO)
	HP, HP(LCC), HP(OPT-45), HP(OPT46G), HP-1+6+S(OPT-40), HP-1+6+S
	P1, P2, P3, P4, P5, P7
	B2, B7
	POSR-1, POSR-2
	5200P, 5300P
	135
	NW-PL, NW-SO
	CG-PILOT
	FG1
REGULATORS	
CONTROL VALVES	RANGER, 987, PREMIER
	964, 521, 988, 988-MB, 989
	2296/2296HF
	SCV-30, SCV-S
	FL800/FL200
TANK BLANKETING	8700, 8910, 8920, 8930, 8940
	2100, 2199
	3100, 3200, 3300, 3400, 3500, 3600, 3700
	1078, 1088, 1100, 1049
	5100, 5200, 5400, 5500
	4100, 4200, 4300, 4400, 4500, 4600
MISC	764P/PD, 764-37, 764T

Cashco, Inc.
P.O. Box 6
Ellsworth, KS 67439-0006
PH (785) 472-4461
Fax. # (785) 472-3539
www.cashco.com
email: sales@cashco.com
Printed in U.S.A. IOM-345

Cashco GmbH
Handwerkerstrasse 15
15366 Hoppegarten, Germany
PH +49 3342 30968 0
Fax. No. +49 3342 30968 29
www.cashco.com
email: germany@cashco.com

Cashco do Brasil, Ltda.
Al.Venus, 340
Indaiatuba - Sao Paulo, Brazil
PH +55 11 99677 7177
Fax. No.
www.cashco.com
email: brazil@cashco.com